Night Leopard



user`s guide

Important Export Restrictions! Commodities, products, technologies and services contained in this manual are subject to one or more of the export control laws and regulations of the U.S. Government and they fall under the control jurisdiction of either the US Department of State or the US BIS-Department of Commerce. It is unlawful and strictly prohibited to export, or attempt to export or otherwise transfer or sell any hardware or technical data or furnish any service to any foreign person, whether abroad or in the United States, for which a license or written approval of the U.S. Government is required, without first obtaining the required license or written approval from the Department of the U.S. Government having jurisdiction. Diversion contrary to U.S. lawis prohibited.





FEATURES

- Rugged fiberglass reinforced plastic construction.
- All glass multi-coated lenses for superb clarity and brightness.
- Revolutionary F1.2 lens with amazing light transmission.
- The Night Leopards infra-red illuminator was designed to let you see even in total darkness.
- Sturdy Hand Strap for comfort of use.
- Camera/camcorder adaptable for night time photography (optional camera adapter required).
- · Weather Resistant.
- Two year warranty.

SPECIFICATIONS

Total Darkness Technology Standar	ď
Magnification3	Χ
Intensifier Tube High Res. 1st Gen	+
Lens System 6 elements, F1:1.2, 50 mr	m
FOV14	۱°
Diopter Adjustment±	5
Power Supply One 3 Volt Lithiui	m
Range Of Focus 1m to Infinit	ij
Controls Digita	al
Battery Life10-20 Hour	s
Operating Temperature40°C to +50°C	
Storage Temperature50°C to +70°C	
Dimensions 175 mm X 85 mm X 50 mm	m
7" X 3.5" X 2	2"
Weight	S

* ATN reserves the right to change the above specifications at any time without notice

APPLICATION

See like a cat in the dark! Our new Night Leopard is a top-notch compact night vision monocular. A new super fast lens system combined with a high resolution Gen. 1+ light intensifier tube gives the user an unparalleled bright image in a 1st gen. night vision device. Easy push button controls, 3x magnification and a built-in infra-red illuminator for viewing in total darkness are just a few of the features this scope packs.

If you want a compact, high quality night vision monocular then look no further then our new Night Leopard.

The Night Leopard Night Vision Monocular is a complex opticoelectronic system for individual use. The device consists of an objective lens assembly, eyepiece and a body. The body contains 1st Gen.+ image intensifier tube assembly with an integrated high voltage power source and the three volt battery housing. When installing the battery one should keep in mind that the battery polarity should coincide with the diagram on the body next to the battery housing cap.

Objective lens protective cover is intended to protect objective lens from dust and scratches. It also will act as a daylight filter, allowing you to test the scope in daylight or other bright light situations. The pinhole in the center of the protective cover allows a user to check an operation ability of the device in daylight conditions.

NOTE: Do not test the scope in daylight conditions even with the daylight filter/lens cap on for more than ten (10) minutes.

OPERATION

- Take the monocular out of the case.
- Install the battery into the housing with the polarity order as shown on the scope. Battery Type: 3 Volt Lithium, #CR123A.
- Press the button marked PWR to turn the unit on with the protective lens cover still attached to the lens. Do not turn the unit on in the daytime without the protective lens cap on. You should see green glow in the eyepiece. You may notice a persistent green glow for up to five (5) minutes after you have turned the unit off. This is normal for the 1st Gen tube.
- Observe the scene and adjust the diopter for optimal image clarity. Focus the front lens until the image and the grain are both sharp.
- You may now enter a dark environment or simply shut the lights off in order to darken the room.
- Next, remove the lens cap/daylight filter.

CAUTION:

THIS PRODUCT CONTAINS NATURAL RUBBER LATEX WHICH MAY CAUSE ALLERGIC REACTIONS.

The information in this manual furnished for information use only, is subject to change without notice, is not to be construed as a commitment by ATN Corp.

ATN Corp. assumes no responsibility or liability for any errors or inaccuracies that may appear in this book. ©2008 ATN Corp. All right reserved.

Adjust the front lens for distance of the focus. You should not have to readjust the diopter.

NOTE: We suggest that you focus the diopter during daylight with the filter on.

NOTE: The front lens should be readjusted as you view objects at different distances.

 To turn the unit off push the button marked PWR again.

USING THE CAMERA ADAPTER (OPTIONAL)

To use your Night Leopard with a 35mm camera or camcorder you will need the following:

- If you plan to use a camcorder, then your camcorder must have a MACRO feature. Most modern camcorders today have a MACRO feature built-in.
- If you plan to use a 35mm camera, you will need a MACRO lens. If you don't have one, we advise that you contact your local camera store.
- You may or may not need a STEP-UP or STEP-DOWN ring in order to adapt the camera adapter to your lens.

NOTE: The camera adapter comes with 37mm and 52mm threads. If you need other sizes your local camera store should be able to help.

- Remove the rubber eyecup from the Night Leopard
- Screw the camera adapter onto the front of the lens on your Video camera's lens or your 35mm camera's lens.
- Loosen the three set screws on the camera adapter.
- Place the camera adapter over the Night Leopard's eyepiece.
- Tighten the three set screws to fit snugly to the Night Leopard's eyepiece
- You may need to focus the 35mm camera or video camera in combination with the Night Leopard in order to get the sharpest possible image.
- We suggest that you find an open space to work in. Focus the Night Leopard so that the scene is at its sharpest. For best results you should disable the auto focus (if any) on either the 35mm camera or the video camera and manually focus the 35mm camera or the video camera. Once the image is sharp, then simply adjust the Night Leopard's front lens to change the focus.

*An important part to remember is that you are not taking a picture of an object that is far away from you, but you are actually taking a picture of the phosphorous screen of the Night Leopard that is only 2-3 inches away.

INFRA-RED ILLUMINATOR

Infra-red (IR) illuminators, are common to night vision. The IR light greatly enhances the performance of the Night Leopard while remaining

almost totally invisible to the naked eye. The IR illuminator on the Night Leopard is located next to the front lens.

To turn the IR on or off push the button marked "IR". It is important to remember that the IR illuminator is simply an infra red light source, and like any light source, it may loose its effectiveness over a great distance.

NOTE: The IR will automatically turn off when the unit's main power switch is turned off.

STORAGE AND CARE

- If the device is not to be us d for extended period of time (more than 10 days) remove the battery.
- Avoid touching lenses. If fingerprints or traces of dirt or dust appear, clean their surface with a Photographic lens cleaning tissue.
- Keep lens cap/daylight filter on when not in use.
- The Night Leopard is not harmful to the user or the environment.
- Do not disassemble except to clean the front lens and eyepiece: it will void your warranty.
- Evaluate the monocular function by looking through it in a lit environment with the daylight filter lens cap on. Never use in daylight without the daylight filter lens cap on.
- Never point the Night Leopard at a bright light source.
- Adverse atmospheric conditions such as fog, smog or haze and a lack of ambient light (moon or starlight) may diminish the effective viewing distance.
- If you use the rubber eyecaps for a long period of time, you may suffer skin inflammation. If you develop any symptoms, consult a doctor immediately.

CLEANING THE EYEPIECE

You may need to clean the eyepiece of the Night Leopard from time to time in order to guarantee top performance. When you receive your Night Leopard you should check for dust on the eyepiece of the unit.

First you will need to remove the eyepiece. To do that you will need to initially loosen the 2 set screws that can be found on the base. Then unscrew the eyepiece counter-clockwise to remove it.

NOTE: You do not have to remove the set screws completely, they are very small and easy to misplace.

CAUTION: Use only Photographic lens cleaning tissue on these surfaces. Be careful not to scratch or smudge any of these surfaces. When using compressed air to blow dust away, make sure to avoid inverting the can while spraying. This can cause frozen propellant to exit the can, which can cause serious problems with the glass and phosphor screen.

TROUBLESHOOTING

- Q: Flashes, flickers or clicking occur while oper-
- S: If it occurs within the first five minutes of inserting new batteries, it is normal and the device will resume normal operation soon thereafter. If it occurs for more than 10 minutes, contact for service instructions.
- Q: Dark spots on screen.
- S: These are either cosme tic blemishes in the intensifier tube or dust particles.
- Q: Screen becomes darker than at previous use.
- S: Replace batteries. If problem persists, contact your dealer or other authorized service representative for service instructions.
- Q: Image not clear.
- S: Adjust objective lens, and/or the eyepiece.

2 YEAR PRODUCT WARRANTY

This product is guaranteed to be free from manufacturing defects in material and workmanship under normal use for a period of 2 (two) years from the date of purchase. In the event a defect that is covered by the foregoing warranty occurs during the applicable period stated above, ATN, at its option, will either repair or replace the product, and such action on the part of ATN shall be the full extent of ATN's liability, and the Customer's sole and exclusive remedy. This warranty does not cover a product (a) used in other than its normal and customary manner; (b) subjected to misuse; (c) subjected to alterations, modifications or repairs by the Customer of by any party other than ATN without prior written consent of ATN; (d) special order or "close-out" merchandise or merchandise sold "as-is" by either ATN or the ATN dealer; or (e) merchandise that has been discontinued by the manufacturer and either parts or replacement units are not available due to reasons beyond the control of ATN. ATN shall not be responsible for any defects or damage that in ATN's opinion is a result from the mishandling, abuse, misuse, improper storage or improper operation, including use in conjunction with equipment which is electrically or mechanically incompatible with or of inferior quality to the product, as well as failure to maintain the environmental conditions specified by the manufacturer. CUSTOMER IS HEREBY NOTIFIED THAT OPERATION OF THE **EQUIPMENT DURING DAYLIGHT HOURS OR** UNDER ANY EXCESSIVE LIGHT CONDITIONS MAY PERMANENTLY DAMAGE THE INTERNAL COMPONENTS OF THE UNIT AND SAID DAMAGE WILL NOT BE COVERED UNDER THIS WAR-**RANTY.** This warranty is extended only to the original purchaser. Any breach of this warranty shall be waived unless the customer notifies ATN at the address noted below within the applicable warranty period.

The customer understands and agrees that except for the foregoing warranty, no other warranties written or oral, statutory, expressed or implied, including any implied warranty of merchantability or fitness for a particular purpose, shall apply to the product. All such implied warranties are hereby and expressly disclaimed.

LIMITATION OF LIABILITY

ATN will not be liable for any claims, actions, suits, proceedings, costs, expenses, damages or liabilities arising out of the use of this product. Operation and use of the product are the sole responsibility of the Customer, ATN's sole undertaking is limited to providing the products and services outlined herein in accordance with the terms and conditions of this Agreement. The provision of products sold and services performed by ATN to the Customer shall not be interpreted, construed or regarded, either expressly or implied, as being for the benefit of or creating any obligation toward any third party of legal entity outside ATN and the Customer; ATN's obligations under this Agreement extend solely to the Customer. ATN's liability hereunder for damages, regardless of the form or action, shall not exceed the fees or other charges paid to ATN by the customer or customer's dealer. ATN shall not, in any event, be liable for special, indirect, incidental or consequential damages, including, but not limited to, lost income, lost revenue or lost profit, whether such damages were foreseeable or not at the time of purchase, and whether or not such damages arise out of a breach of warranty, a breach of agreement, negligence, strict liability or any other theory of liability.

PRODUCT WARRANTY REGISTRATION

In order to validate the warranty on your product, ATN must receive a completed Product Warranty Registration Card for each unit or complete warranty registration on our website at www.atncorp.com. Please complete the included form and immediately mail it to our Service Center: ATN Corporation, 1341 San Mateo Avenue, South San Francisco, CA 94080.

OBTAINING WARRANTY SERVICE

To obtain warranty service on your unit, please contact our Customer Service department and request an RMA number. Once you have received your RMA # please mark this # on the outside of the shipping box and take or send the product, postage paid, with a copy of your sales receipt to our service center, ATN Corporation at the address noted above. All merchandise must be fully insured with the correct postage; ATN will not be responsible for improper postage or missing or damaged merchandise during shipment. Packages that do not have an RMA # clearly marked on the outside of the package will be delayed in being processedt.

For customer service and technical support, please contact American Technologies Network Corp. North American Office

1341 San Mateo Avenue South San Francisco, CA 94080

phone: 800-910-2862, 650-989-5100; fax: 650-875-0129

European Office phone: 44(0)870-0111286, fax: 44(0) 845-3349142

The following countries can use our toll free number 00 800 9102-8620 Austria, France, Germany, Holland, Italy,

Spain, Sweden, Switzerland

www.atncorp.com